
## AlphaScreen® SureFire®: 2-plates/ 1-step assay flowchart (p-ERK1/2 and p-MEK1 kits only)



<sup>&</sup>lt;sup>1</sup> Depending on cell type and pathway analyzed.

<sup>&</sup>lt;sup>2</sup> Depending on type of inhibitor used: 5 min is generally enough for receptor antagonists; more time is needed to block intracellular targets.

<sup>&</sup>lt;sup>3</sup> May stop and freeze lysates at -20°C if desired. If doing this, re-shake after thawing to ensure homogeneity of solution.